

Narrogin Airfield

VHF Pilot Activated Lighting.

Instructions

ACTIVATION FROM AIRCRAFT

Under normal circumstances, pilots of incoming aircraft will activate the lights using their VHF radio.

Frequency 119.6 MHz - 3 x 3 second pulses within 25 seconds.

The system has an Automatic Frequency Response Unit attached that talks back to the incoming aircraft.

Ground Activation.

- 1. Insert key into switch on side of cabinet. **Do not turn key**
- 2. Turn outer switch **on & then OFF**. **Do not turn key**

It should also be noted that the key only needs to be inserted into switch. It should never be turned.

Key available through Flying Club, Gliding Club, Ambulance.

Any problems should be reported to the Shire Council or Grant Froome.
Phone 98811866 or 0429101810